



















HP Media Center PC

Start Here



What's in the Box?

Included	
Keyboard, mouse, wireless receiver	
Documentation	
IR remote control plus two AA batteries	
Remote sensor	
FM antenna	
Modem cable	
Remote IR cable (1 or 2, select models only)	
Composite video cable	
Analog video cable (select models only)	
TV coaxial cable (1 or 2, select models only)	
AC power cable (110–240V~, 50–60 Hz)	

Not Included (may need to purchase)	
Coaxial splitter (select models only)	
Wireless LAN antenna (for extended range)	
DVI cable	
RCA Y cable	
Extra TV coaxial cables	
S-video cable	
Component video cable	

Installation Overview

Set Up Your PC — Complete All 5 Steps:

1. Initial Setup

- a) Connect Keyboard and Mouse **2**
- b) Set Up Remote Control **3**
- c) Connect FM Antenna **3**

2. Audio **5**

3. Video **13**

4. TV Signal Sources **19**





5. Final Setup

- a) Internet Connection **25**
- b) Power On **26**
- c) Software Setup **27**

Keyboard and Mouse

Wireless Keyboard/Mouse Receiver (select models only)



Refer to installation instructions included with your keyboard and mouse.





Remote Control and FM Antenna

Remote Control

Install AA
batteries in
remote control.




FM Antenna (select models only)




Audio – Choose Your Configuration


1 Choose your PC



or



or



Audio

2 Choose one

Page

- a) PC speakers 6
- b) Home stereo AV receiver 9
- c) TV speakers 9
- d) Digital audio 12

Choose one

Page

- a) PC speakers 7
- b) Home stereo AV receiver 10
- c) TV speakers 10
- d) Digital audio 12

Choose one


Page

- a) PC speakers 8
- b) Home stereo AV receiver 11
- c) TV speakers 11
- d) Digital audio 12

Audio — PC Speakers


Select only one audio option, then proceed to video.

2.0/2.1 Channel Speakers




Refer to setup instructions that came with your speakers.

5.1 Channel Speakers




Refer to setup instructions that came with your speakers.

7.1 Channel Speakers






Refer to setup instructions that came with your speakers.



or

or




When you are done with audio, proceed to video.

Audio — PC Speakers


Select only one audio option, then proceed to video.

2.0/2.1 Channel Speakers




Refer to setup instructions that came with your speakers.

5.1 Channel Speakers



Refer to setup instructions that came with your speakers.


7.1 Channel Speakers



Creative Labs Model T7700
(or equivalent only)
Refer to setup instructions and cables that came with your speakers.

or

or




When you are done with audio, proceed to video.

Audio — PC Speakers


Select only one audio option, then proceed to video.

2.0/2.1 Channel Speakers






Refer to setup instructions
that came with your speakers.

5.1 Channel Speakers



Refer to setup instructions
that came with your speakers.




When you are done with audio, proceed to video.


Audio — Home Stereo AV Receiver or TV Speakers

Select only one audio option, then proceed to video.

2 Channel AV Receiver or TV Analog connections



Audio input jacks




or

5.1 Channel AV Receiver Analog connections



Audio input jacks





or

7.1 Channel AV Receiver Analog connections




Audio input jacks



When you are done with audio, proceed to video.

Audio — Home Stereo AV Receiver or TV Speakers


Select only one audio option, then proceed to video.



When you are done with audio, proceed to video.

Audio — Home Stereo AV Receiver or TV Speakers

Select only one audio option, then proceed to video.



When you are done with audio, proceed to video.


Audio — Home Stereo AV Receiver with Digital Audio Input

Select only one audio option, then proceed to video.

5.1 Channel AV Receiver




Digital audio input jack



or

5.1 Channel AV Receiver




Digital audio input jack




or

5.1 Channel AV Receiver





Digital audio input jack




or


NOTE:
Your PC will have only one of these connector locations.



A



B




C


When you are done with audio, proceed to video.

Video – Choose Your Configuration

1 Choose your graphics card



or



2 Choose one

Page

- a) High-definition TV 14
- b) Standard TV 16
- c) PC display 18


Choose one

Page

- a) High-definition TV 15
- b) Standard TV 17
- c) PC display 18

Video — High Definition TVs


Select only one video option, then proceed to TV signal sources.



When you are done with video, proceed to TV signal sources.

Video — High-Definition TVs


Select only one video option, then proceed to TV signal sources.



When you are done with video, proceed to TV signal sources.

Video — Standard TVs


Select only one video option, then proceed to TV signal sources.



When you are done with video, proceed to TV signal sources.

Video — Standard TVs


Select only one video option, then proceed to TV signal sources.



When you are done with video, proceed to TV signal sources.

Video — PC Displays

Select only one video option, then proceed to TV signal sources.



When you are done with video, proceed to TV signal sources.


TV Signal Sources

Choose your TV signal source:

- 1. Analog Cable** **21**
- 2. Analog Antenna** **21**
- 3. Cable Box or Satellite Receiver** **22**
 - Remote Control** **23**
- NOTE:** You must use the HP remote sensor and IR transmitter to use the remote control with your box.
- 4. Digital TV Antenna**
(select models only) **24**

TV Signal Sources — Analog Cable or Antenna

Connect TV signal to PC, then proceed to final setup.




When you are done with TV signal, proceed to final setup.

TV Signal Sources — Cable or Satellite Receiver — Step 1


Connect TV signal to PC, then proceed to step 2.

Step 1


Single Set-top Box




From first cable box or satellite receiver rear panel.



(optional) Second Set-top Box (select models only)



From second cable box or satellite receiver rear panel.



Complete
the Required
Next Step

NOTE: Use **(B)** connectors if you have a dual tuner card and a second identical cable box or a second identical satellite receiver.


B

A

A

B


TV Signal Sources – Cable or Satellite Receiver – Step 2



When you are done with TV signal, proceed to final setup.


TV Signal Sources — Digital TV Antenna

Connect TV signal to PC, then proceed to final setup.




Final Setup — Internet Connection

Select only one network option, then proceed to Power On.




Wireless LAN (802.11b/g)



Refer to network setup wizard for configuring the HP Media Center PC to your home network




Attach 802.11 b/g antenna (select models only)




Wired LAN


From DSL or cable modem or network router



Ethernet (RJ45 cable)




Dial-up Modem (select models only)




Final Setup — Power On

Power Connection




Power On


Turn on power in the order shown.



1



2



3

Final Setup — Software Setup

When you first turn on your system:

- 1) Follow the onscreen instructions, and answer any questions.
- 2) When the Windows desktop appears, set up your Internet connection and verify that it's working by navigating to your Web home page.
- 3) Start Media Center by aiming your Media Center remote control at the remote sensor and pressing the green Start button.
- 4) The Media Center setup wizard starts and guides you through the initialization process.
- 5) If you have a high-definition digital tuner, the Digital TV wizard starts and guides you through the digital TV configuration process.
- 6) For instructions on configuring speaker and sound options, and configuring audio output, refer to the *Getting Started Guide* that came with your PC.
- 7) For further instructions on using your HP Media Center PC, refer to the *Getting Started Guide*, *Software Guide*, *Warranty and Support Guide*, and other documentation that came with your PC. You may also go to **<http://www.hp.com/support>** for more information.
- 8) **Enjoy!**

Copyright © 2005 Hewlett-Packard Development Company, L.P.

Printed in

www.hp.com



5 9 9 1 - 2 9 4 7